

# Operating Instructions

## The Meade® Green Laser Pointer

### Introduction

Your laser pointer uses two AAA batteries. It is recommended that you use alkaline batteries. Remove the batteries if you are not planning to use it for long periods.

To install or change the batteries, unthread the cap at the clip end of the laser pointer. Insert the batteries so that the "+" end points towards the cap. Replace the cap.

To turn on the laser, press and hold down the On/Off button. Release the button to turn off.

The laser pointer is not designed to be held in the On positions for long periods of time; rather, use it in short bursts to conserve the battery life.

**Do not** look directly at the laser light or shine the beam into the eyes of another person or animal. The laser can be harmful to eyes. **Do not** point the laser at any vehicle, aircraft, vessel or other moving object. **Do not** use the laser while operating any vehicle or equipment. Temporary blindness can occur. Keep out of the reach of children and **do not** let children use the laser as a toy.

Be courteous when using the laser pointer at star parties and try not to interfere with the observations of others. Some star parties forbid the use of green laser pointers. Check with the organizers of your star party for further information.

### SPECIFICATIONS

Wavelength . . . . . 532+/-10nm  
Output . . . . . <5mW  
Distance . . . . . up to 25,000 feet  
Operating Current . . . . . 150mW  
Operating Voltage . . . . . 3V  
Operating Temp . . . . . 77°F/25 °C  
Battery . . . . . 2x AAA (Included)

If you have a question concerning use of the Meade **GREEN LASER POINTER**, call the Meade Instruments Customer Service Department at (800) 626-3233. Customer Service hours are 8:00 AM to 5:00 PM, Pacific Time, Monday through Friday.




Fig. 1: Install the batteries.

### MEADE LIMITED WARRANTY

This accessory is warranted by Meade Instruments Corp. ("Meade") to be free of defects in materials and workmanship for a period of ONE YEAR from the date of original purchase in the U.S.A. and Canada. Meade will repair or replace a product, or part thereof, found by Meade to be defective, provided the defective part is returned to Meade, freight-prepaid, with proof of purchase. This warranty applies to the original purchaser only and is non-transferable. Meade products purchased outside North America are not included in this warranty, but are covered under separate warranties issued by Meade international distributors.

**RGA Number Required:** Prior to the return of any product or part, a Return Goods Authorization (RGA) number **must** be obtained from Meade by writing, or calling (800) 626-3233. Each returned part or product must include a written statement detailing the nature of the claimed defect, as well as the owner's name, address, and phone number.

This warranty is not valid in cases where the product has been abused or mishandled, where unauthorized repairs have been attempted or performed, or where depreciation of the product is due to normal wear-and-tear. Meade specifically disclaims special, indirect, or consequential damages or lost profit which may result from a breach of this warranty. Any implied warranties which cannot be disclaimed are hereby limited to a term of one year from the date of original retail purchase.

This warranty gives you specific rights. You may have other rights which vary from state to state.

Meade reserves the right to change product specifications or to discontinue products without notice.

**AVOID DIRECT EXPOSURE  
LASER RADIATION--  
AVOID DIRECT EYE CONTACT**  
Laser Radiation is Emitted from  
the APERTURE

**DANGER**



Keep Pointer Away from Children

Laser Diode/Class IIIa Laser Product  
Wavelength: 532+/-10nm  
Max Output Power <5mW



**MEADE®**

6001 Oak Canyon, Irvine, California 92618  
(800) 626-3233 ■ www.meade.com

